

How to Upgrade the Firmware in the Smart Plug

Configuration Steps

1. You can download the latest version utility “FWUpgradeTool” (click here to download) to your PC or notebook.
2. Confirm your smart plug already connected to the same network as your PC or netebook.
3. Access utility “FWUpgradeTool” and choose one plug you will upgrade and check the status to see if it can be upgraded or whether you already have the latest upgrade installed. If you can’t find the plug you are looking, you can use the search function.
4. When you have successfully located the plug you wish to install, click “Upgrade”. Before you update the firmware, you need to connect your PC or notebook to the same network as the installed smart plug that you want to update firmware. Then access the download utility and the access screen as below.

